

## Hoopeston Demo Derby

### **Bone Stock 108 FWD Wire Compacts/Van RULES:**

1. All cars need to be stripped and cleaned out (as much as possible) for safety.
2. Need to move the battery and gas tank inside the car, SECURE THEM, no leaks.
3. May run stock, mud, or donut tires.
4. Hood and Trunk – allowing six spots on each, sheet metal to sheet metal only. Optional: Two of these spots can go down to the bumper.
5. May 9 wire all doors closed or you may weld the driver's door with two pieces of 12" x 1" flat stock and 9 wire all other doors closed. THIS IS FOR YOUR SAFETY.
6. Cage – needs to be a 4-point cage. You may have a down bar on the driver and passenger sides (for safety purposes). This CANNOT reinforce the car in any way.
7. Bumpers – you may use any automobile bumper you like or you may use a 4x4 square tube bumper/bumper shocks can be 8" x 2" square tube, welded inside of the front frame, welded to the front bumper, no gussets. For SAFETY reasons, bumpers may not hang out wider than the car.
8. There are no aftermarket parts in this class. What is listed above is what you get. This is a very easy build, please do not overthink it.

*If you have any questions about any of the rules listed above, general questions, or would like more information, please contact Taylor Feldkamp.*